

OPTICAL M O U S E

RF-160

SETUP

1. Open Battery Compartment

Place the RF-160 face up in your hand with the wheel toward you. With your index finger of your other hand, pull the tab on the underside of the case toward the front. This will release the top battery cover. With your other hand, press down lightly on the cover and slide it back. The cover should slide easily from the mouse.

2. Install Batteries

Insert included AA alkaline batteries into the mouse's battery compartment.

Note: The batteries face in opposite directions.

3. Connect USB Receiver

Plug the receiver into a USB port on your computer.

Tip: Do not place receiver on or in a metal cabinet or near strong EMI sources.

4. Set Address

Press and release the button on the underside of the receiver. While the LED on the receiver blinks, press the address button on the underside of the mouse. This sets the mouse and receiver to one of 65,000 random addresses.

5. (Optional) Set More Devices To Control This Computer.

Press and release the button on the underside of the receiver and then press the address setting button(s) on each device (refer to each device's instructions for specifics). You have 30 seconds to address each device. Once a device gets the address, the receiver waits another 30 seconds for additional devices.

OPERATION

The RF-160 is designed to operate reliably at distances of 50 feet (15 meters) or more. Pressing a button or moving the mouse makes the LEDs flash green on the sides of the mouse, and the LED on the receiver blink green.

Note: Operating range will vary depending on positioning of the receiver, mouse, nearby sources of interference and other factors.

Note: The RF-160 will go to sleep after 30 minutes of inactivity to save battery power. To wake up the RF-160, press one of the mouse buttons.



WIRELESSTM
COMPUTING

www.wireless-computing.com

TROUBLESHOOTING

The receiver LED is not lit

- Ensure that the computer is powered on and the receiver is connected to computer.

Mouse moves don't get to the computer

- If the LEDs on the mouse flash all red, set the address.
- If the LEDs flash mixed red and green, reposition the receiver and ensure it is within 50 feet.
- If the LEDs do not flash at all, replace the batteries.
- Unplug the receiver and plug it back into the computer.

The LEDs do not flash when the mouse is moved

- Remove and re-insert the batteries.

The RF-160 works, but other Wireless Computing devices don't

- The other devices aren't set to the receiver's address. Set the address on all devices.

The cursor moves by itself or keystrokes appear from nowhere

- Your receiver is within range another Wireless Computing device set to the same address. Set the address.

FOR FURTHER ASSISTANCE

Visit www.wireless-computing.com/support or call customer support at 512.858.4400 between 8:30 - 5:30 Central Time.

FCC INFORMATION

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Consult the dealer or a Wireless Computing technician for help.

The radio module has been evaluated under FCC bulletin OET 65C and found compliant to the requirements as set forth in CFR 47 sections 2.1049, 15.203, 15.209 and 15.249 addressing RF exposure from radio frequency devices.

Tested to comply with FCC standards.

FCC ID: L7MR160 RF-160 Optical Mouse
L7MR019 RF-019 Dual Antenna Receiver

ADDITIONAL INFORMATION

For use with UL Listed, CSA approved personal computers. Not intended for use in machinery, medical or industrial applications. Do not use in aircraft or hazardous locations.

<p>Caution: Any changes or modifications not expressly approved by Wireless Computing could void your authority to operate this device. No parts are user serviceable.</p>
