

WIRELESS KEYBOARD

RF-220

INSTRUCTIONS

1. **Install Battery.** Insert two AA alkaline batteries (included) in keyboard's battery compartment.
2. **Connect USB Receiver.** If your RF-220 has a USB receiver, plug the receiver into a USB port on your computer. Don't connect anything to the two jacks on the receiver's side unless you are using an RF-020 1000' Extender.
3. **Connect PS/2 Receiver.** If your RF-220 has a PS/2 receiver, first turn off power to the computer. Connect the keyboard and mouse plugs to the corresponding PS/2 ports on your computer. Then turn the computer's power on.


Tip: Do not place receiver in an equipment cabinet or near other strong EMI sources.

4. **Set Address To Enable Encryption.** Press and release the momentary switch on the underside of the receiver. While the green LED on the receiver

blinks, hold down the **Fn** key and press the "**A**" key. This sets the keyboard and receiver to one of 32,000 random addresses and enables encryption.

Tip: If you do not set its address, your RF-220 will operate, but encryption will be disabled.

5. **(Optional) Set More Devices To Control This Computer.** To set a second RF-220 to control this computer, hold down its **Fn** key and press its **A** key before the green LED on the receiver stops blinking. To set additional devices to control this computer, set its address before the green LED on the receiver stops blinking.
6. **For Macintosh Only.** To set the keyboard to Macintosh mode, press the **Left-Win**, **Left-Alt**, **Right-Win** and **Right-Alt** keys at the same time. Next, detach the **Win**, **Alt**, and **Pause/Break** keycaps and replace with **Command**, **Option/Alt** and **F13** keycaps as shown below.



OPERATION

The RF-220 is designed to operate reliably at distances of 100 feet (31 meters) or more. Pressing a key or moving the mouse stick makes the “sending” LED flash green on the keyboard, and the green LED on the receiver blink.

Operating range will vary depending on positioning of the receiver and keyboard, nearby sources of interference, and other factors.

When the red “low battery” LED turns on, replace the batteries as soon as possible.

TROUBLESHOOTING

Green LED on receiver is not lit

- Ensure computer is powered on and receiver is connected to computer.

Key presses don't get to computer

- If the sending LED on the keyboard flashes all red, reset the address.
- If the sending LED flashes mixed red and green, reposition the receiver and ensure it is within 100'.
- If the sending LED does not flash at all, replace the batteries in the keyboard.
- Also try unplugging then re-plugging the receiver.

Windows Start menu opens when press Alt

- Keyboard is in Macintosh mode. Change to Windows mode by pressing Left-**Win**, Left-**Alt**, Right-**Win** and Right-**Alt** keys all at the same time.

RF-220 works, but other Wireless Computing devices do not

- The other devices aren't set to the receiver's address. Reset the address on all devices.

On Mac, Option and Command keys reversed

- Keyboard is in Win mode. Change to Macintosh mode by pressing Left-**Option**, Left-**Cmd**, Right-**Cmd** and Right-**Option** keys all at the same time.

Cursor moves by itself, or keystrokes appear “from nowhere”

- The address of your receiver may be the same as the address of another RF-220 within range. Reset the address.

FOR FURTHER ASSISTANCE

Visit www.wireless-computing.com/support or call customer support at 512.858.4400 between 9:00-5:00 Central Time.

FCC INFORMATION

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

Reorient or relocate the receiving antenna.

Increase the separation between the equipment and receiver.

Consult the dealer or a Wireless Computing technician for help.

The radio module has been evaluated under FCC bulletin OET 65C and found compliant to the requirements as set forth in CFR 47 sections 2.1049, 15.203, 15.209 and 15.249 addressing RF exposure from radio frequency devices.

Tested to comply with FCC standards.

FCC ID: L7MR220 RF-220 Compact Keyboard
L7MR015 RF-01x Wireless Receiver

ADDITIONAL INFORMATION

For use with UL Listed, CSA approved personal computers. Not intended for use in machinery, medical or industrial applications. Do not use in aircraft or hazardous locations.

Caution: Any changes or modifications not expressly approved by Wireless Computing could void your authority to operate this device. No parts are user serviceable.